

FAZEON

27" LED MONİTÖR
KULLANIM KLAVUZU
VE GARANTİ BELGESİ

X27F200

FAZEON

FAZEON Her karede üstün performans, her oyunda tam kontrol!
Oyuncu monitörlerimiz, ultra hızlı yenileme hızları ve çarpıcı görsel netlik sunarak
oyun deneyiminizi zirveye taşıyor. Gecikmesiz tepki süresi ve canlı renklerle
donatılmış bu monitörler, sizi oyunun tam kalbine götürmek için tasarlandı.
Kazanmak için ihtiyaç duyduğunuz her şey burada!"

KULLANIM KILAVUZU

Sayın Müşterimiz,

Bu ürünü satın aldığınız için teşekkür ederiz. Bu belge LCD renkli monitörün nasıl kurulacağını ve kullanılacağını açıklamaktadır. Doğru ve güvenli kullanım için bilgiler içeren bu kılavuzu dikkatlice okuyun. Gerekğinde başvurabilmeniz için bu kılavuzu elinizin altında bulundurun.

ÜRÜN TANIMI VE KULLANIM TÜRÜ

LCD renkli monitör çok sağlam bir yapı sunar. Sürekli çalışma için tasarlanmıştır ve kapalı devre TV sistemlerinde aşırı yorulma riski olmadan kullanılabilir. Düz Panel Ekran aktif matrisli, ince film transistörlü (TFT), sıvı kristal ekrana (LCD) sahiptir.

GENEL ÖZELLİKLER

- Gösterge alanı
- Birlikte verilmeyen braket ile duvara montaj
- Bir kompozit video girişi, iki DP, iki HDMI
- Otururken veya ayakta dururken ve bir konumdan diğerine geçerken görüntülemeye olanak tanıyan geniş eğim Ekranın kolay ayarlanması ve optimizasyonu için çok dilli OSD menüsü

KUTUNUN AÇILMASI

Ambalajın ve içindekilerin gözle görülür şekilde hasar görmediğini kontrol edin. Parçalar eksik veya hasarlıysa derhal satıcıyla iletişime geçin. Bu durumda cihazı kullanmaya çalışmayın. Hasar görmüşse ürünü orijinal ambalajında geri gönderin.

KUTU İÇERİĞİ

- LCD monitör
- Güç adaptörü
- Güç kablosu
- DP kablosu
- Kullanım kılavuzu

Önemli Not: Aksesuarlar önceden haber verilmeksizin değiştirilebilir.

UYARILAR

GÜÇ

- Cihazı çalıştırmak için yalnızca sağlanan güç ünitesini kullanın. Güç ünitesini fişe takmadan önce şebeke değerini kontrol edin.
- Cihazın fişini çekmek için kabloyu çekmeyin.

GÜVENLİK ÖNLEMLERİ

- Yangın ve elektrik çarpması riskini önlemek için cihazı yağmur ve nemden uzak tutun. İçine malzeme (katı veya sıvı) sokmayın. Kazara böyle bir durum meydana gelirse, cihazın elektrik bağlantısını kesin ve yetkili personel tarafından kontrol edilmesini sağlayın.
- Cihazı asla açmayın. Her durumda, onarım için kalifiye personele veya yetkili servis merkezine başvurun.
- Kazara hasar gömesini önlemek için cihazı çocuklardan uzak tutun.
- Elektrik çarpmasını veya mekanik hasarı önlemek için cihaza ıslak elle dokunmayın.
- Cihaz düşerse veya dış kasası hasar görürse cihazı kullanmayın. Cihaz bu koşullarda kullanılırsa elektrik çarpması riski vardır. Satıcıya veya yetkili montajcıya başvurun.
- Monitör belirli bir süre kullanılmıyorsa güç kablosunun çıkarılması tavsiye edilir.

KURULUM ÖNLEMLERİ

- Cihazın aşırı ısınmasını önlemek için, cihazı kasadaki yuvalardan hava akışına izin verecek bir konuma yerleştirin. Bir rafın içine monte ederken en az 5 cm boş alan olduğundan emin olun. Aynı nedenle, radyatör veya sıcak hava kanalları gibi ısı kaynakları monte etmeyin. Doğrudan güneş ışığından uzak tutun. Aşırı toza, mekanik titreşimlere veya darbelere maruz kalan alanlara kurmayın.
- Bu cihazı, sallanan veya eğimli bir masa gibi dengesiz bir yüzeye yerleştirmeyin. Cihaz düşerek yaralanmalara veya mekanik arızalara neden olabilir.
- Cihazı neme veya suya maruz kalabileceği bir yere kurmayın. Cihazın üzerine su püskürtmeyin: yangın, elektrik çarpması veya mekanik arıza riski.
- İçine su veya başka bir madde girmesi durumunda cihazı kullanmayı bırakın: yangın ve elektrik çarpması riski. Satıcıya veya yetkili montajcıya başvurun.
- Kabindeki yuvalar ve açıklıklar havalandırma için sağlanmıştır. Bu açıklıklar engellenmemeli veya kapatılmamalıdır.
- Cihazın üzerine ağır veya ısı üreten nesneler koymayın: bu, kasaya zarar verebilir ve/veya iç sıcaklığı artırarak arızalara neden olabilir.
- Dış kasanın deforme olmasını ve iç parçaların aşırı ısınmasını önlemek için cihaz çalışırken üzerini bir bezle örtmeyin: yangın, elektrik çarpması ve mekanik arıza riski.
- Arızaları önlemek için mıknatısları ve mıknatıslı nesneleri cihazdan uzak tutun.
- Cihazı duman, buhar, nem, toz veya yoğun titreşimlerin bulunduğu ortamlarda kullanmayın.
- Bir cihazı soğuk bir yerden sıcak bir yere veya tam tersi bir yere taşıdıktan hemen sonra çalıştırmadan önce bir süre bekleyin. Monitör plastik bir taban ve lastik ayaklarla donatılmıştır. Masa veya sehpa gibi yatay bir yüzey üzerine yerleştirilebilir.
- Monitör plastik bir taban ve lastik ayaklarla donatılmıştır. Cihazın sıkıca sabitlendiğinden ve dengesiz desteklere veya yüzeylere dayanmadığından emin olun. Düşmesi ciddi yaralanmalara neden olabilir ve cihaza zarar verebilir.
- Mükemmel bir görüntü elde etmek için parlaklığı ve kontrastı ayarlamayı unutmayın.
- Monitör, bir braket (birlikte verilmez) aracılığıyla duvara da monte edilebilir.

1.3.4 CİHAZIN TEMİZLENMESİ



- Toz ve kiri temizlemek için kuru bir bezle nazıkçe ovun.
- Kir sadece kuru bir bezle giderilemiyorsa bezi nötr deterjana batırın.
- Boyanın deforme olmasını, bozulmasını veya çizilmesini önlemek için cihazı temizlemek için uçucu sıvılar (benzin, alkol, çözücüler vb.) veya kimyasal işlem görmüş giysiler kullanmayın.

1.3.5 MAHREMİYET VE TELİF HAKKI

- LED monitör Oyun için bir cihazdır. Görüntülerin kaydedilmesi ülkenizde yürürlükte olan yasalara tabidir. Telif hakkı ile korunan görüntülerin kaydedilmesi yasaktır.

Ürün kullanıcıları, video sinyallerinin izlenmesi ve kaydedilmesiyle ilgili tüm yerel kural ve düzenlemeleri kontrol etmek ve bunlara uymakla sorumludur. Bu ürünün yürürlükteki yasalara uygun olmayan kullanımından imalatçı SORUMLU OLMAYACAKTIR.

Monitör girişleri




- ❶ Power (DC 12V, 4A)
- ❷ HDMI2
- ❸ HDMI1
- ❹ DP2
- ❺ DP1
- ❻ AUDIO OUT


Uyarı: Her zaman uygun güç kablosunu kullanın.

Aksesuar


Kutu İçeriği




27inch Monitor




Stand



DP Kablo




Güç Adaptöre ve
Güç Kablosu



Kullanıcı Kılavuzu

Monitör Kontrol Düğmeleri




①	A	Sinyal kaynağını seçin veya OSD Çıkışı
②	M	Ana OSD Menüsünü açın ve alt menüyü seçin
③	▲	Ana OSD Menüsünde Yukarı Git Seçilen bir öğenin değerini artırın mI
④	▼	Ana OSD Menüsünde Aşağı Git Seçilen bir öğenin değerini azaltma
⑤	⏻	Monitörü Açma veya Kapatma

İLK KURULUM

Monitörü bir elektrik prizine bağlayın.

1. Monitör üzerindeki POWER düğmesine basın veya monitörü açın (Gösterge mavi olacaktır).
2. İlgili kabloyu monitördeki ilgili girişe bağlayın. Kaynak otomatik olarak algılanacaktır.
3. Girişler arasında geçiş yapmak için, kaynak menüsüne girmek üzere "Kaynak" düğmesine basın. düğmesini kullanın. Giriş kaynağını Otomatik Seçim, DP1, DP2 ve HDMI1, HDMI2 arasından seçmek için " "ve" " düğmelerini kullanın.



OSD MENÜ

A. Giriş Kaynağı

DP1		Resolution: 2560x1440@180Hz
Input Source	☒ Auto Source	
Brightness/Contrast	DP1	
Color Setting	DP2	
Picture Quality Setting	HDMI1	
Display	HDMI2	
OSD		
Others		

Sinyal girişini DP1, DP2, HDMI1, HDMI2 olarak değiştirin veya monitörün kaynağı Otomatik Seçmesini sağlayın.

B . Parlaklık/Kontrast

DP1		Resolution: 2560x1440@180Hz
Input Source	Brightness	80
Brightness/Contrast	Contrast	50
Color Setting	Black Level	50
Picture Quality Setting	Sharpness	100
Display	Eco	Standard
OSD	DCR	Off
Others		

Parlaklık: Ekran parlaklık değerini 0 ila 100 arasında değiştirin.

Kontrast: Ekran kontrast değerini 0 ila 100 arasında ayarlayın.

Siyah Seviyesi: Ekran siyah seviyesi değerini 0 ila 100 arasında değiştirin.

Keskinlik: Ekran keskinlik değerini 0 ila 100 arasında değiştirin.

Eko: Eko modunu şu şekilde değiştirin: Standad, Fotoğraf, Oyun, FPS, Film,

RTS. DCR: Açık veya Kapalı.

C . Renk Ayarı

DP1		Resolution:2560x1440@180Hz
Input Source	Color Temperature	Warm
Brightness/Contrast	Red	43
Color Setting	Green	50
Picture Quality Setting	Blue	41
Display		
OSD		
Others		

Renk Sıcaklığı: Renk sıcaklığı modunu şu şekilde değiştirin: Sıcak, Normal, Soğuk, Kullanıcı.

D . Görüntü Kalitesi Ayarı

DP1		Resolution:2560x1440@180Hz
Input Source	Super Resolution	Off
Brightness/Contrast	MPRT	Off
Color Setting	Volume	50
Picture Quality Setting	Mute	Off
Display		
OSD		
Others		

Süper Çözünürlük: Süper çözünürlük modunu şu şekilde değiştirin: Kapalı, Düşük, Orta, Yüksek.

MPRT: Açık veya Kapalı.

Ses Seviyesi: Ekran ses seviyesi değerini 0 ila 100 arasında değiştirin.

Sessiz: Açık veya Kapalı: Açık veya Kapalı.

E . Ekran

DP1		Resolution:2560x1440@180Hz
Input Source	Aspect Ratio	Wide Screen
Brightness/Contrast	FreeSync[Adaptive Sync]	Off
Color Setting	Overdrive	Off
Picture Quality Setting		
Display		
OSD		
Others		

Süper Çözünürlük: En boy oranı modunu şu şekilde değiştirin: Geniş Ekran, 4:3 olarak değiştirin. FreeSync[Adaptive Sync]: Açık veya Kapalı.
Overdrive: Açık veya Kapalı.

F . OSD

DP1		Resolution:2560x1440@180Hz
Input Source	Language	English
Brightness/Contrast	OSD H.Position	50
Color Setting	OSD V.Position	50
Picture Quality Setting	OSD Transparency	20
Display	OSD Time Out	20
OSD		
Others		

Dil: OSD Menüsü görüntüleme dilini değiştirin.

OSD H.Pozisyonu: OSD Menüsünün yatay konumunu değiştirin.

OSD V.Konumu: OSD Menüsünün dikey konumunu değiştirin.

OSD Şeffaflığı: OSD Menüsünün saydamlık değerini 0 ila 100 arasında değiştirin.

OSD Zamanlayıcı Çıkışı: OSD Menüsünün otomatik olarak çıkmadan önce ne kadar süre açık kalacağını değiştirin.

H. Diğər

DP1		Resolution:2560x1440@180Hz
Input Source	HDR	Off
Brightness/Contrast	Led Effect	On
Color Setting	Reset	
Picture Quality Setting	Low Blue Mode	0
Display	Flicker Free	On
OSD		
Others		

HDR: Açık veya Kapalı.

Led Efekti: Açık veya Kapalı.

Sıfırla: Orijinal ayarları geri yükleyin.

Düşük Mavi Modu: Ekran düşük mavi modu değerini 0 ila 100 arasında

değiştirin. Titreşimsiz: Açık veya Kapalı.

Teknik Özellikler

Model No.:	YMG27DFI-200HZ
Ekran Boyutu	27"
Panel Tipi	IPS
Arka ışık tipi	LED
En Boy Oranı	16:9
Parlaklık (Tipik.)	350cd/m ²
Kontrast Oranı (Tipik.)	1000:1
Çözünürlük	2560x1440 @ 200Hz
Tepki Süresi (OD ile Maks.)	MPRT 1ms
Görüş Açısı (Yatay/Dikey)	178°/178° (CR>10) IPS
Renk Desteği	16.7M (8bit 100% sRGB)
Video Sinyali	Analog RGB/Digital
Senkronizasyon. Sinyal	Separate H/V, Composite, SOG
Konektör	HDMIx2+DPx2
Güç Tüketimi	Typical 34W
Bekleme Gücü (DPMS)	<0.5W
Tür	DC12V, 5A
Freesync ve Adaptif senkronizasyon	Supported
HDR	Supported
Tak ve Çalıştır	Supported
Dolap Rengi	Matt Black
Flick ücretsiz	Supported
Aşırı Sürücü	Supported
Düşük Mavi Işık Modu	Supported
RGB ışık	Supported
VESA montajı	100x100mm
Ses	2x3W

HDMI™ The terms HDMI, HDMI High-Definition Multimedia Interface, HDMI Trade dress and the HDMI Logos are trademarks or registered trademarks of HDMI Licensing Administrator, Inc.

KULLANICININ DİKKATİNE

1. Cihazı Kurmadan Önce

- Monitörünüzü kullanmadan önce bu kılavuzu dikkatlice okuyun.
- Monitörünüzü açmadan önce tüm ambalaj malzemelerini ve koruyucu filmleri çıkarın.

2. Güvenlik Uyarıları

- Monitörü yalnızca belirtilen voltajda bir güç kaynağına bağlayın.
- Cihazın üzerine sıvı dökmemeye özen gösterin.
- Monitörü aşırı sıcak, nemli veya tozlu ortamlarda kullanmayın.
- Güç kablosunu sıkışma veya ezilmelere karşı koruyun.

3. Kurulum ve Bağlantı

- Monitörünüzü düz ve stabil bir yüzeye yerleştirin.
- Cihazı kurarken, havalandırma deliklerinin kapatılmadığından emin olun.
- Kabloları bağlamadan önce cihazın kapalı olduğundan emin olun.

4. Kullanım Sırasında Dikkat Edilmesi Gerekenler

- Uzun süreli kullanımlarda göz sağlığını korumak için düzenli aralıklarla mola verin.
- Monitörün parlaklık ve kontrast ayarlarını, göz yorgunluğunu en aza indirecek şekilde ayarlayın.
- Cihazın arkasında bulunan bağlantı noktalarına zarar verebilecek sert hareketlerden kaçının.

5. Bakım ve Temizlik

- Monitörünüzü temizlemeden önce mutlaka fişini prizden çekin.
- Ekranı temizlemek için yumuşak, kuru bir bez kullanın.
Sert kimyasal temizleyiciler kullanmayın.

6. Sorun Giderme

- Monitör açılmıyorsa, güç kablosunun doğru bağlandığından ve prizde elektrik olduğundan emin olun.
- Görüntüde titreme veya renk bozukluğu varsa bağlantı kablolarını kontrol edin.

7. Garanti ve Teknik Destek

- Ürününüz garanti kapsamındaysa yetkili servis dışında müdahalede bulunmayın.
- Teknik destek için kullanım kılavuzunda belirtilen iletişim bilgilerini kullanabilirsiniz.

KULLANICI HATALARI

1. Yanlış Voltaj Kullanımı

- Monitörü belirtilen voltaj dışında bir güç kaynağına bağlamak, cihazın arızalanmasına veya tamamen bozulmasına neden olabilir.
- Çözüm: Monitörün güç adaptörünün ve priz voltajının uyumlu olduğundan emin olun.

2. Havalandırma Deliklerinin Kapatılması

- Monitörün arka kısmındaki havalandırma deliklerinin kapatılması, cihazın aşırı ısınmasına yol açar ve donanımına zarar verebilir.
- Çözüm: Monitörü, havalandırmanın serbest kalacağı şekilde yerleştirin ve çevresinde en az 10 cm boşluk bırakın.

3. Sıvı Teması

- Monitöre sıvı dökülmesi kısa devreye ve kalıcı hasara neden olabilir.
- Çözüm: Monitörü sıvılardan uzak bir yerde konumlandırın ve sıvı dökülmesi durumunda cihazı hemen kapatarak yetkili servise başvurun.

4. Yanlış Kablo Bağlantıları

- HDMI, DisplayPort veya güç kablosunun yanlış takılması görüntü sorunlarına veya bağlantı noktalarının hasar görmesine neden olabilir.
- Çözüm: Kabloları bağlamadan önce doğru bağlantı noktalarını kontrol edin ve bağlantıları yavaşça gerçekleştirin.

5. Sert Müdahaleler

- Monitörün ekranına sert cisimlerle dokunmak veya bastırmak ekranın çatlamasına ya da piksel bozukluklarına yol açabilir.
- Çözüm: Ekranı yalnızca yumuşak bir bezle müdahale edin ve fiziksel darbelerden kaçının.

6. Uzun Süreli Sabit Görüntü Kullanımı

- Uzun süre aynı görüntünün ekranda kalması, "görüntü yanması" (burn-in) sorununa neden olabilir.
- Çözüm: Monitörünüzde ekran koruyucu kullanın veya uzun süreli kullanımlarda ekrandaki görüntüyü değiştirin.

7. Uyumsuz Yazılım ve Sürücü Kullanımı

- Monitörle uyumsuz sürücülerin veya yazılımların yüklenmesi, görüntü performansında sorunlara yol açabilir.
- Çözüm: Üreticinin önerdiği sürücüler ve yazılımları kullanın.

8. Yanlıř Temizlik Yöntemleri

- Sert kimyasal temizleyiciler veya ıslak bez kullanmak, ekranın kaplamasına zarar verebilir.
- Çözüm: Ekranı temizlerken yalnızca yumuřak, kuru veya hafif nemli bir mikrofiber bez kullanın.

9. Monitörün Dengesiz Yüzeylere Yerleřtirilmesi

- Monitörün eğik veya dengesiz bir yüzeye yerleřtirilmesi, düşme veya devrilme riskine yol açabilir.
- Çözüm: Monitörü düz, stabil ve kaymaz bir yüzeye yerleřtirin.

10. Yetkisiz Müdahaleler

- Monitörün iç kısmına yetkisiz müdahale edilmesi, cihazın garanti kapsamı dıřına çıkmasına ve daha büyük arızalara neden olabilir.
- Çözüm: Cihazda bir sorun olduėunda yalnızca yetkili servise başvurun.kullanım kılavuzunda belirtilen iletiřim bilgilerini kullanabilirsiniz.

ARIZA VE TEKNİK DESTEK

1. Hasar Durumunda Yapılması Gerekenler;

Fiziksel Hasar;

- Cihazda çatlak, kırık veya ezik gibi fiziksel hasarlar fark ederseniz:
- Monitörü kullanmayı derhal durdurun.
- Cihazın elektrik bağlantısını kesin ve fişi prizden çekin.
- Fiziksel hasarların garanti kapsamı dışında değerlendirilebileceğini unutmayın. Yetkili servisle iletişime geçin.

Görüntü Sorunları;

- Ekranda titreme, renk bozulması veya görüntü kaybı gibi sorunlar varsa:
- Bağlantı kablolarını kontrol edin ve sıkıca takılı olduklarından emin olun.
- Farklı bir kablo veya cihaz kullanarak sorunun monitörden kaynaklanıp kaynaklanmadığını test edin.
- Sorun devam ederse teknik destek alın.

Elektrik Sorunları;

- Monitör açılmıyorsa veya düzensiz çalışıyorsa:
- Güç kablosunun sağlamlığını kontrol edin.
- Prizin çalıştığından emin olmak için farklı bir elektrik kaynağı deneyin.
- Sorun çözülmezse cihazı yetkili servise götürün.

2. Teknik Destek Alımı

Yetkili Servis;

- Monitörünüzde herhangi bir sorun tespit ettiğinizde, yalnızca üretici tarafından yetkilendirilmiş servis merkezlerinden destek alın.
- Yetkisiz müdahaleler cihazın garanti kapsamı dışında kalmasına neden olabilir.


İletişim;

- Teknik destek için üreticinin müşteri hizmetleriyle iletişime geçebilirsiniz. İletişim bilgileri genellikle kullanım kılavuzunda veya ürün kutusunda yer alır.
- Cihazın seri numarasını ve satın alma belgesini yanınızda bulundurun.

3. Teknik Destek Alırken Dikkat Edilmesi Gerekenler

- Cihazı servise göndermeden önce kişisel ayarlarınızı ve verilerinizi yedekleyin.
- Servis merkezine gönderim sırasında monitörünüzü orijinal ambalajında veya güvenli bir şekilde paketleyerek koruyun.ü ve güvenli bir şekilde çalışabilmesi için yalnızca yetkili teknik destekten yardım almanız önerilir.

UYGUNLUK BEYANI



Aşağıda belirtilen ürünün, Avrupa Birliği'nin CE işareti gerekliliklerine uygun olduğunu beyan ederiz. Bu beyan, ürünün ilgili Avrupa Birliği direktifleri ve standartlarına uygun olarak tasarlandığını, üretildiğini ve test edildiğini garanti eder.

Ürün Testi ve Değerlendirme;

Bu ürün, belirtilen standartlara uygunluğu doğrulamak amacıyla yetkili test laboratuvarlarında test edilmiştir.

Marka: FAZEON

Model: X27F200

Bu uygunluk beyanı, yalnızca yukarıda belirtilen ürünler için geçerlidir ve Avrupa Birliği pazarında CE işareti ile kullanılmasına izin verir.

Not: Bu belge, ürünün CE işareti gerekliliklerini karşıladığını ve AB standartlarına uygun olduğunu resmi olarak belgelemektedir.



Ürün veya ürün ambalajının üzerinde bu sembolün görülmesi halinde bu atık ev eşyası atığı olarak atılamaz. Atığınızı, elektrikli ve elektronik cihazların geri dönüşümünü için uygulanabilir geri alma şemasına göre ele alarak atmalısınız. Bu donanımın geri dönüşümü hakkında daha fazla bilgi için yerel bayiye yada mağazaya başvurunuz. Materyallerin geri dönüşümü doğal kaynakların korunmasını ve insan sağlığına ve çevreye zarar verilmeksizin geri dönüştürülmesini güvence etmektedir.

GARANTİ ŞARTLARI

Garanti Süresi;

- Garanti süresi, ürünün satın alındığı tarihten itibaren *2 yıl* geçerlidir. Satış belgesi (fatura veya fiş) garanti süresinin başlangıç tarihi olarak kabul edilir.

Garanti Kapsamı;

- Garanti, ürünün üretim ve malzeme hatalarından kaynaklanan arızaları kapsar.
- Kasa içindeki dahili bileşenler (fanlar, RGB aydınlatmalar, USB portlar vb.) garanti kapsamındadır.

Garanti Dışında Kalan Durumlar;

- Kullanıcı hatasından kaynaklanan hasarlar (örneğin, yanlış montaj, aşırı güç uygulama, sıvı teması, düşme veya darbe).
- Yetkisiz kişiler tarafından yapılan tamir veya modifikasyonlar.
- Yanlış voltaj kullanımı sonucu oluşan arızalar.
- Normal kullanım sonucu oluşan aşınma ve yıpranma (örneğin, boyanın solması veya çizilmesi).

Garanti Hizmetinden Yararlanma;

- Garanti talebinde bulunmak için, ürünle birlikte satış belgesi ve garanti belgesi ibraz edilmelidir.
- Ürün, orijinal ambalajında veya uygun bir şekilde paketlenerek teknik servise gönderilmelidir.

Tamir ve Değişim Süreci;

- Garanti kapsamında onarılabilir arızalar ücretsiz olarak tamir edilir.
- Onarım mümkün değilse, ürün yenisiyle değiştirilir veya eşdeğer bir ürünle ikame edilir.
- Onarım veya değişim süresi, ürünün teknik servise ulaşmasından itibaren en fazla *20 iş günü*dür.

Ürün İade ve Değişim Şartları;

- Ürün, satın alındıktan sonraki *14 gün* içinde kusursuz ve kullanılmamış bir durumda iade edilebilir.
- Kusurlu ürünlerde, garanti süresi boyunca değişim veya iade işlemi yapılabilir.

Kullanıcı Sorumlulukları;

- Ürün kullanım kılavuzuna uygun şekilde kullanılmalıdır.
- Aşırı ısıya, neme veya sıvı temasına karşı dikkatli olunmalıdır.

Yasal Haklar;

- Bu garanti şartları, Tüketici Kanunu'nda belirtilen haklara ek olarak sunulmaktadır ve yasal haklarınızı kısıtlamaz.

GARANTİ BELGESİ

Satıcı firmanın

Ünvanı

: G5F Teknoloji San. Tic. A.Ş.

Adres

: Yukarı Dudullu Mah. Necip Fazıl Bulvarı
Keyap Ticaret Merkezi E2 Blok No: 44/87
Ümraniye / İSTANBUL

Destek Merkezi

: +90 (212) 212 7485

Kaşe

:

G5F TEKNOLOJİ
SANAYİ TİCARET ANONİM ŞİRKETİ
Yukarı Dudullu Mh. Necip Fazıl Blv.
No:44/87 Ümraniye/İstanbul
Sancaklı V.D.:3881881884

MALIN

Cinsi

: Oyuncu monitörü

Markası

: FAZEON

Modeli

: X27F200

Bandrol ve seri no

:

Beslim tarihi ve yeri

:

Azami tamir süresi

: 20 iş günü

Garanti

: 3 yıl

Satıcı firmanın

Ünvan

:

Adresi

:

Tel-faks

:

Fatura tarihi ve no

:

FAZEON

FAZEON

27" LED MONITOR
**USER MANUAL
AND WARRANTY CERTIFICATE**

X27F200

The logo for FAZEON, featuring the brand name in a stylized, uppercase, sans-serif font. The letters are black and have a modern, geometric feel. The background of the entire page is a light gray, with a large, white, diagonal stripe running from the top left towards the bottom right, creating a dynamic visual element.

FAZEON

FAZEON Superior performance in every frame, total control in every game!
Our gaming monitors take your gaming experience to the next level with ultra-fast refresh rates and stunning visual clarity. Equipped with lag-free response times and vibrant colors, these monitors are designed to take you right to the heart of the game.
Every thing you need to win is right here!

GENERAL INFORMATION

Dear Customer,

Thank you for having purchased this product. This document describes how to install and use the LCD colour monitor. Read this manual which contains information for correct, safe use carefully. Keep this manual at hand so that you can refer to it when needed.

PRODUCT DESCRIPTION AND TYPE OF USE

The LCD color monitor presents a very rugged structure. It is designed for continuous operation and can be used in closed circuit TV systems without risks of excessive fatigue. The Flat Panel Display has an active matrix, thin-film transistor (TFT), liquid crystal display (LCD).

GENERAL FEATURES

- Display area
- Wall mounting with not included bracket
- One composite upgrade, two DP, two HDMI
- Wide inclination to allow viewing either from a seated position or standing up and when moving from one position to the other

Multilingual OSD menu for easy setting and optimization of the display

OPENING THE BOX

Check that the packing and the contents are not visibly damaged. Contact the retailer immediately if parts are either missing or damaged. Do not attempt to use the device in this case. Send the product back in its original packing if it is damaged.

CONTENTS OF THE BOX

- LCD monitor
- Power Adaptor
- Power cable
- DP cable
- User's manual

Important Note: Accessories may be changed without prior notice.

WARNINGS

POWER

- Only use the power unit provided to power the device. Check mains rating before plugging the power unit in.
- Do not pull the cable to unplug the device.

SAFETY PRECAUTIONS

- Keep the device away from rain and humidity to prevent risk of fire and electrocution. Do not introduce material (solid or liquid) inside. If this should accidentally occur, disconnect the device from the mains and have it inspected by qualified personnel.
- Never open the device. In all cases, contact the qualified personnel or authorized service center for repairs.
- Keep the device away from children, to prevent accidental damage.
- Do not touch the device with wet hands to prevent electrical shock or mechanical damage.
- Do not use the device if it should fall or the external casing is damaged. Risk of electrocution if the device is used in such conditions. Contact the retailer or authorized installer.
- It is advisable to disconnect the power wire if the monitor is not used for a certain time.

INSTALLATION PRECAUTIONS

- To prevent overheating the device, arrange it in a position allowing the flow of air through the slots in the casing. Ensure at least 5 cm of free space when installing inside a rack. For the same reason, do not install sources of heat, such as radiators or hot air ducts. Keep away from direct sunlight. Do not install in areas subject to excessive dust, mechanical vibrations or shocks.
- Do not arrange this device on an unstable surface, such as a tottering or slanted table. The device could fall causing injury or mechanical failures.
- Do not install the device in a place where it could be exposed to humidity or water. Do not direct a jet of water onto the device: risk of fire, electrocution or mechanical failure.
- Stop using the device if water or other material should penetrate inside: risk of fire and electrocution. Contact the retailer or authorized installer.
- Slots and openings in the cabinet are provided for ventilation. These openings must not be blocked or covered.
- Do not place heavy or heat generating objects on top of the device: this could damage the casing and/or increase internal temperature causing faults.
- Do not cover the device with a cloth while it is running to prevent deforming the external casing and overheating the internal parts: risk of fire, electrocution and mechanical failure.
- Keep magnets and magnetized objects away from the device to prevent faults.
- Do not use the device in presence of smoke, vapor, humidity, dust or intense vibrations.
- Wait for a while before operating a device immediately after transporting it from a cold place to a warm place and vice versa. Wait on average for three hours: this will allow the device to adapt to the new ambient (temperature, humidity, etc.).
- The monitor is provided with a plastic base and rubber feet. It can be positioned on a horizontal surface, such as a desk or a table. Make sure that the device is fastened firmly and that it is not resting on unstable supports or surfaces. Dropping could cause severe injury and damage the device.
- Remember to adjust the brightness and contrast to obtain a perfect image.
- The monitor can also be installed on the wall by means of a bracket (not provided).

1.3.4 CLEANING THE DEVICE



- Rub delicately with a dry cloth to remove dust and dirt.
- Dip the cloth in neutral detergent if dirt cannot be eliminated with a dry cloth alone.
- Do not use volatile liquids (such a petrol, alcohol, solvents, etc.) or chemically treated clothes to clean the device to prevent deformation, deterioration or scratches to the paint finish.

1.3.5 PRIVACY AND COPYRIGHT

- The LED monitor is a device for Gaming. Recording of images is subject to the laws in force in your country. Recording of images protected by copyright is forbidden.

Product users shall be responsible for checking and respecting all local rules and regulations concerning monitoring and recording video signals. The manufacturing SHALL NOT BE LIABLE for use of this product not in compliance with the laws in force.

Monitor Inputs



- ❶ Power (DC 12V, 4A)
- ❷ HDMI2
- ❸ HDMI1
- ❹ DP2
- ❺ DP1
- ❻ AUDIO OUT


***WARNING:** Always use the appropriate power cord.

Accessories


PACKAGE INCLUDES




27inch Monitor




Stand



DP Cable




Power Adapter
and Power Cable



User Manual

Monitor Control Buttons




①	A	Select signal source or Exit OSD
②	M	Open the Main OSD Menu and Select submenu
③	▲	Go Up on the Main OSD Menu Increase the value of a selected itemI
④	▼	Go Down on the Main OSD Menu Decrease the value of a selected item
⑤	⏻	Turn the monitor on or Off

INITIAL SETUP

Connect the monitor to a power outlet.

1. Press the POWER button on the monitor or to turn it on (The indicator will be blue).
2. Connect the relevant cable to the corresponding input on the monitor. The source will be automatically detected.
3. To change between inputs, press the "Source" button to enter the source menu. Use the "◀" and "▶" buttons to choose the input source between Auto Select, DP1, DP2, and HDMI1, HDMI2.



OSD MENU

A. Input Source

DP1		Resolution:2560x1440@180Hz
Input Source	☒ Auto Source	
Brightness/Contrast	DP1	
Color Setting	DP2	
Picture Quality Setting	HDMI1	
Display	HDMI2	
OSD		
Others		

Switch the signal input to DP1,DP2,HDMI1,HDMI2,or have the monitor Auto Select the source.

B . Brightness/Contrast

DP1		Resolution:2560x1440@180Hz
Input Source	Brightness	80
Brightness/Contrast	Contrast	50
Color Setting	Black Level	50
Picture Quality Setting	Sharpness	100
Display	Eco	Standard
OSD	DCR	Off
Others		

Brightness: Change the display brightness value from 0 to 100.

Contrast: Adjust the display contrast value from 0 to 100.

Black Level: Change the display black level value from 0 to 100.

Sharpness: Change the display sharpness value from 0 to 100.

Eco: Change the eco mode to: Standad, Photo, Game, FPS, Movie, RTS.

DCR: On or Off.

C . Color Setting

DP1		Resolution:2560x1440@180Hz
Input Source	Color Temperature	Warm
Brightness/Contrast	Red	43
Color Setting	Green	50
Picture Quality Setting	Blue	41
Display		
OSD		
Others		

Color Temperature: Change the color temperature mode to: Warm, Normal, Cool, User.

D . Picture Quality Setting

DP1		Resolution:2560x1440@180Hz
Input Source	Super Resolution	Off
Brightness/Contrast	MPRT	Off
Color Setting	Volume	50
Picture Quality Setting	Mute	Off
Display		
OSD		
Others		

Super Resolution: Change the super resolution mode to: Off, Low, Middle, High.

MPRT: On or Off.

Volume: Change the display volume value from 0 to 100.

Mute: On or Off.

E . Display

DP1		Resolution:2560x1440@180Hz
Input Source	Aspect Ratio	Wide Screen
Brightness/Contrast	FreeSync[Adaptive Sync]	Off
Color Setting	Overdrive	Off
Picture Quality Setting		
Display		
OSD		
Others		

Super Resolution: Change the aspect ratio mode to: Wide Screen, 4:3.

FreeSync[Adaptive Sync]: On or Off.

Overdrive: On or Off.

F . OSD

DP1		Resolution:2560x1440@180Hz
Input Source	Language	English
Brightness/Contrast	OSD H.Position	50
Color Setting	OSD V.Position	50
Picture Quality Setting	OSD Transparency	20
Display	OSD Time Out	20
OSD		
Others		

Language: Change the OSD Menu display language.

OSD H.Position: Change the horizontal position of the OSD Menu.

OSD V.Position: Change the vertical position of the OSD Menu.

OSD Transparency: Change the transparency value of the OSD Menu from 0 to 100.

OSD Timer Out: Change how long the OSD Menu is on before it automatically exits.

H. Other

DP1		Resolution:2560x1440@180Hz
Input Source	HDR	Off
Brightness/Contrast	Led Effect	On
Color Setting	Reset	
Picture Quality Setting	Low Blue Mode	0
Display	Flicker Free	On
OSD		
Others		

HDR: On or Off.

Led Effect: On or Off.

Reset: Restore the original settings.

Low Blue Mode: Change the display low blue mode value from 0 to 100.

Flicker Free: On or Off.

Technical Specificaions

Model No.:	YMG27DFI-200HZ
Screen Size	27"
Panel Type	IPS
Backlight type	LED
Aspect Ratio	16:9
Brightness (Typical.)	350cd/m ²
Contrast Ratio (Typical.)	1000:1
Resolution	2560x1440 @ 200Hz
Response Time (Max. with OD)	MPRT 1ms
Viewing Angle (Horizontal/Vertical)	178°/178° (CR>10) IPS
Color Support	16.7M (8bit 100% sRGB)
Video Signal	Analog RGB/Digital
Sync. Signal	Separate H/V, Composite, SOG
Connector	HDMIx2+DPx2
Power Consumption	Typical 34W
Stand By Power (DPMS)	<0.5W
Type	DC12V, 5A
Freesync and Adaptive sync	Supported
HDR	Supported
Plug & Play	Supported
Cabinet Color	Matt Black
Flick free	Supported
Over Driver	Supported
Low BLue Light Mode	Supported
RGB light	Supported
VESA mount	100x100mm
Audio	2x3W

HDMI™ The terms HDMI, HDMI High-Definition Multimedia Interface, HDMI Trade dress and the HDMI Logos are trademarks or registered trademarks of HDMI Licensing Administrator, Inc.

USER'S ATTENTION

1. Before Installing the Device

- Read this manual carefully before using your monitor.
- Remove all packaging materials and protective films before opening your monitor.

2. Safety Precautions

- Connect the monitor to a power source of the specified voltage only.
- Be careful not to spill liquid on the device.
- Do not use the monitor in extremely hot, humid or dusty environments.
- Protect the power cord from being pinched or crushed.

3. Installation and Connection

- Place your monitor on a flat and stable surface.
- When installing the device, make sure that the ventilation holes are not blocked.
- Make sure the device is turned off before connecting cables.

4. Cautions During Use

- Take regular breaks to protect your eye health during prolonged use.
- Adjust the monitor's brightness and contrast settings to minimize eye strain.
- Avoid sharp movements that may damage the connection points on the back of the device.

5. Maintenance and Cleaning

- Always unplug your monitor before cleaning it.
- Use a soft, dry cloth to clean the screen.

Do not use harsh chemical cleaners.

6. Troubleshooting

- If the monitor does not turn on, make sure the power cable is connected correctly and there is power in the outlet.
- If there is flickering or discoloration in the image, check the connection cables.

7. Warranty and Technical Support

- If your product is under warranty, do not intervene except for authorized service.
- You can use the contact information provided in the user manual for technical support.

USER ERRORS

1. Incorrect Voltage Usage

- Connecting the monitor to a power source other than the specified voltage may cause the device to malfunction or completely break down.
- Solution: Make sure that the monitor's power adapter and the wall outlet voltage are compatible.

2. Blocking the Ventilation Holes

- Blocking the ventilation holes on the back of the monitor may cause the device to overheat and may damage the hardware.
- Solution: Place the monitor so that ventilation is free and leave at least 10 cm of space around it.

3. Liquid Contact

- Liquid spills on the monitor may cause a short circuit and permanent damage.
- Solution: Keep the monitor away from liquids and in the event of a liquid spill, turn off the power immediately and contact authorized service.

4. Incorrect Cable Connections

- Incorrectly connecting the HDMI, DisplayPort or power cable may cause image problems or damage to the ports.
- Solution: Check the correct ports before connecting the cables and make the connections slowly.

5. Rough Interventions

- Touching or pressing the monitor screen with hard objects may cause the screen to crack or pixel defects.
- Solution: Only touch the screen with a soft cloth and avoid physical impacts.

6. Long-Term Fixed Image Use

- Keeping the same image on the screen for a long time may cause "image burn-in" problem.
- Solution: Use a screen saver on your monitor or change the image on the screen during long-term use.

7. Incompatible Software and Driver Use

- Installing drivers or software that are incompatible with the monitor may cause problems in image performance.
- Solution: Use drivers and software recommended by the manufacturer.

8. Incorrect Cleaning Methods

- Using harsh chemical cleaners or wet cloths may damage the coating of the screen.
- Solution: Use only a soft, dry or slightly damp microfiber cloth when cleaning the screen.

9. Placing the Monitor on Unstable Surfaces

- Placing the monitor on a slanted or unstable surface may cause a risk of falling or tipping over.
- Solution: Place the monitor on a flat, stable, and non-slip surface.

10. Unauthorized Interventions

- Unauthorized interventions inside the monitor may void the warranty and cause more serious malfunctions.
- Solution: In case of a problem with the device, contact only an authorized service.
You can use the contact information provided in the user manual.

FAILURE AND TECHNICAL SUPPORT

1. What to do in case of damage;

Physical Damage;

- If you notice physical damage such as cracks, breaks or dents on the device:
- Stop using the monitor immediately.
- Disconnect the device from the power supply and unplug it.
- Remember that physical damages may be considered outside the scope of warranty.

Contact an authorized service.

Image Problems;

- If there are problems such as flickering, color distortion or image loss on the screen:
- Check the connection cables and make sure they are firmly connected.
- Test whether the problem is caused by the monitor by using a different cable or device.
- If the problem persists, get technical support.

Electrical Problems;

- If the monitor does not turn on or works erratically:
- Check the strength of the power cable.
- Try a different power source to make sure the outlet is working.
- If the problem persists, take the device to an authorized service.

2. Getting Technical Support

Authorized Service;

- If you detect any problem with your monitor, only get support from service centers authorized by the manufacturer.
- Unauthorized interventions may void the warranty of the device.

Contact;

- You can contact the manufacturer's customer service for technical support. Contact information is usually provided in the user manual or on the product box.
- Have the serial number and proof of purchase of the device with you.

3. Things to Consider When Getting Technical Support

- Back up your personal settings and data before sending the device for service.
 - Protect your monitor in its original packaging or by packing it securely during shipment to the service center.
- and it is recommended that you only get help from authorized technical support for safe operation.

DECLARATION OF CONFORMITY

EU REGULATIONS DECLARATION OF COMPLIANCE

We declare that the product specified below complies with the CE marking requirements of the European Union. This declaration guarantees that the product has been designed, manufactured and tested in accordance with the relevant European Union directives and standards.

Product Testing and Evaluation;

This product has been tested in authorized test laboratories to verify compliance with the specified standards.

Marka: FAZEON

Model: X27F200

This declaration of conformity is only valid for the products listed above and allows use in the European Union market with the CE marking.

Note: This document officially documents that the product meets the CE marking requirements and complies with EU standards.



If this symbol appears on the product or product packaging, this waste cannot be disposed of as household waste. You must dispose of your waste by handling it in accordance with the applicable take-back scheme for the recycling of electrical and electronic equipment. For more information on recycling this equipment, please contact your local dealer or store. Recycling of materials ensures the conservation of natural resources and recycling without harming human health or the environment.

WARRANTY CONDITIONS

Warranty Period;

- The warranty period is valid for *2 years* from the date of purchase of the product.
- The sales document (invoice or receipt) is accepted as the starting date of the warranty period.

Warranty Scope;

- The warranty covers malfunctions caused by manufacturing and material defects of the product.
- Internal components inside the case (fans, RGB lighting, USB ports, etc.) are under warranty.

Situations Not Covered by Warranty;

- Damages caused by user error (e.g. incorrect assembly, excessive force application, liquid contact, falling or impact).
- Repairs or modifications made by unauthorized persons.
- Malfunctions caused by incorrect voltage usage.
- Wear and tear caused by normal use (e.g. paint fading or scratching).

Benefiting from Warranty Service;

- In order to make a warranty claim, the sales document and warranty document must be presented together with the product.
- The product must be sent to the technical service in its original packaging or packaged appropriately.

Repair and Replacement Process;

- Repairable faults under warranty are repaired free of charge.
- If repair is not possible, the product is replaced with a new one or an equivalent product. The repair or replacement period is a maximum of *20 business days* from the date the product reaches the technical service.

Product Return and Replacement Conditions;

- The product can be returned in a flawless and unused condition within *14 days* after purchase. Defective products can be replaced or returned during the warranty period.

User Responsibilities;

- The product must be used in accordance with the user manual.
- Care must be taken against excessive heat, humidity or liquid contact.

Legal Rights;

- These warranty terms are provided in addition to the rights specified in the Consumer Law and do not limit your legal rights.

WARRANTY CERTIFICATE

Seller's

Title : G5F Teknoloji San. Tic. A.Ş.
Address : Yukarı Dudullu Mah. Necip Fazıl Bulvarı
Keyap Ticaret Merkezi E2 Blok No: 44/87
Ümraniye / İSTANBUL
Support Center : +90 (212) 212 7485
Stamp :

**GOODS**

Type : Gaming monitor
Brand : FAZEON
Model : X27F200

Bandroll and serial number :
Delivery date and place :
Maximum repair period : 20 working day
Warranty : 3 year

Seller's

Title :
Address :
Phone-fax :
Invoice date and number :

FAZEON